

SECTION 5

AIR FLOW AND FAN BLADE SPACING

AIR FLOW DIAGRAMS & EVAPORATOR FAN-BLADE SPACING

This section illustrates the direction of air flow through the evaporators, and proper evaporator fan blade spacings of each model.




Figure 5-1. Air Flow - Model 601R




Figure 5-2. Air Flow - Model 601F




Figure 5-3. Air Flow - Model 611, 650

Clamp Forward




Figure 5-4. Air Flow - Model 632, 642




Figure 5-5. Air Flow - Model 690